


Three-phase motor connected to run on single phase

The strips need to be set up for motor to run in delta mode (as pictured)



...or if the rotation needs reversing, use the connections below

